


3-Axis Subsystems for Laser Beam Deflection

AXIALSCAN, FOCUSHIFTER



This manual has been compiled by RAYLASE for its customers and employees.

RAYLASE reserves the right to change the product described in this manual and the information contained therein without prior notice.

The software included in the product and this manual itself are protected by copyright. All rights are reserved. Duplication of this manual in whole or in part, particularly by photocopying, scanning or imaging, and reproduction by any means are forbidden without the prior, written consent of RAYLASE.

CONTENTS

1	BASIC SAFETY INSTRUCTIONS	5
1.1	Laser safety.....	5
1.2	Laser shutter.....	5
1.3	Signs.....	5
1.4	Classification of laser devices	6
1.5	Laser area	7
2	BASIC INFORMATION	8
2.1	Introduction.....	8
2.2	Package contents.....	8
2.3	Module overview	9
2.4	Warranty.....	10
2.5	Manufacturer	10
2.6	Customer Service.....	10
2.7	Status LED of the linear translator module	11
2.7.1	Analog linear translator modules.....	11
2.7.2	Digital linear translator modules	11
2.8	Status LEDs of the deflection unit	12
2.8.1	Analog deflection units	12
2.8.2	Digital deflection units	12
3	TECHNICAL DATA	13
3.1	Rating plate code	13
3.1.1	Deflection Unit	14
3.1.2	Linear Translator Module	15
3.1.3	Linear Translator Module (FOCUSSHIFTER).....	15
3.2	Conformity with directives	16
4	FUNCTIONAL DESCRIPTION	17
4.1	Laser beam subsystem	17
4.2	Functional principle of analog subsystems	18
4.3	Functional principle of digital subsystems.....	19
4.4	Protection window	24
4.5	F-Theta lens	25
4.6	Interfaces of the linear translator module.....	26
4.6.1	Analog input.....	26
4.6.2	Digital input.....	27
4.6.3	Power supply.....	28
4.6.4	Stepper motor interface.....	29
4.6.5	Digital output.....	30
4.7	Interfaces of the deflection unit	31
4.7.1	Analog input.....	31
4.7.2	Power supply.....	32
4.7.3	Digital interface.....	33
5	INSTALLATION	34
5.1	Installing the linear translator module	35
5.2	Checking the beam coupling: AXIALSCAN (Standard), AXIALSCAN (motorized), FOCUSSHIFTER (Standard)	36
5.2.1	Preparation.....	36
5.2.2	Checking procedure	37
5.2.3	Assembly.....	38
5.3	Checking the beam coupling: AXIALSCAN (water cooled).....	39

5.3.1	Preparation	39
5.3.2	Checking procedure.....	40
5.3.3	Assembly	41
5.4	Manually adjusting the field size	42
5.4.1	Preparation	42
5.4.2	Adjustment procedure:: AXIALSCAN (standard).....	43
5.4.3	Adjustment procedure: AXIALSCAN (water cooled)	44
5.5	Motorized field size adjustment	45
6	CLEANING	46
6.1	Cleaning the housing	46
6.2	Cleaning the optical system.....	46
6.2.1	Instructions for cleaning F-Theta lenses and protection windows	47
6.2.2	Instructions for cleaning focusing lenses and mirrors.....	47
6.2.3	Special instructions for zinc selenide optical elements	48
7	MAINTENANCE	50
8	TROUBLESHOOTING	51

1 BASIC SAFETY INSTRUCTIONS

1.1 Laser safety

The user is responsible for safe operation and for safeguarding the surrounding area against hazards that can be caused by laser radiation. OEM customers must ensure compliance with all local and national regulations.


1.2 Laser shutter

The subsystem - consisting of a linear translator module and a deflection unit - is designed to focus and deflect an input laser beam and output it again. The subsystem cannot block or weaken the laser beam. To prevent unwanted emission of the laser beam, above a particular danger class the laser device must be fitted with a shutter (⇒ page 6, Classification of laser devices).

The laser device must be of sufficient quality that the laser beam can only be emitted at the beam output on the deflection unit.

1.3 Signs

The following signs must be attached to the subsystem. These signs may not be removed. Signs that have become illegible must be replaced.



The **rating plates** and the identification codes printed on them can be used to determine the type of the linear translator module and the deflection unit (⇒ page 13, Rating plate code). The serial number and the item number are also used to identify the subsystem.



The **ground symbol** identifies the ground connection on the subsystem. This connection can be connected to the laser housing via a plug connection to increase the interference resistance.



The **CE symbol** confirms the subsystem's compliance with European directives. It indicates that the subsystem is approved for free trade within the EU.



The **seal labels** warn against unauthorized opening of the subsystem. If a seal is broken, all warranty claims against RAYLASE are void.



A **laser warning sign** must be attached at the point where laser radiation is emitted. This provides information about the type of radiation, specific hazards and the degree of protection. The laser warning sign is attached by the OEM customer in accordance with the laser device's classification (⇒ page 6, Classification of laser devices).

1.4 Classification of laser devices

The subsystem can be fitted on various laser devices. Every laser device is assigned to a particular danger class, which must be specified at the point where laser radiation is emitted, e.g. using a warning sign. The following classifications are defined in DIN EN 60825-1:

Class	Description
1	The accessible laser radiation is not dangerous under reasonable foreseeable conditions.
1M	The accessible laser radiation is in the wavelength range of 302.5nm to 4,000nm. The accessible laser radiation is not dangerous to the eyes, as long as the cross-section is not reduced by optical instruments (magnifying glasses, lenses, telescopes).
2	The accessible laser radiation is in the visible spectrum (400nm to 700nm). Short-term exposure (up to 0.25s) is not dangerous to the eyes. Additional radiation components outside the wavelength range from 400nm-700nm meet the requirements for class 1.
2M	The accessible laser radiation is in the visible spectrum from 400nm to 700nm. Short-term exposure (up to 0.25s) is not dangerous to the eyes, as long as the cross-section is not reduced by optical instruments (magnifying glasses, lenses, telescopes). Additional radiation components outside the wavelength range from 400nm-700nm meet the requirements for class 1M.
3R	The accessible laser radiation is in a wavelength range of 302.5nm to 10,600nm and is dangerous to the eyes. The power or energy is a maximum of five times the limit for permissible class 2 radiation in the wavelength range from 400nm to 700nm.
3B	The accessible laser radiation is dangerous to the eyes and frequently to the skin.
4	The accessible laser radiation is extremely dangerous to the eyes and dangerous to the skin. Even diffuse scattered radiation can be dangerous. The laser radiation can cause fires or a risk of explosion.

Note: Bear in mind that the subsystem changes the position at which the beam is emitted and the new beam output must be marked with a warning sign showing the appropriate classification.

Note: The subsystem can change the classification of the laser device, particularly if it is fitted with a focusing lens. The laser device may require additional protective equipment as a result.

1.5 Laser area

For the purposes of accident prevention, the laser area is defined as the area in which the maximum permitted radiation value can be exceeded. This is generally applicable for class 3B, 3R and 4 lasers. For class 1 to 2M laser devices, a laser area can be produced by focusing the laser beam.

A sufficient beam intensity produces a laser area that covers the entire radiation angle of the subsystem and includes the reflection from all objects that can be exposed to the radiation as a result. Note that even apparently diffuse surfaces can reflect laser radiation and a laser beam that has been reflected several times can still be dangerous.

The laser area must be indicated by corresponding warning signs or lamps and protected by appropriate shading and interlock switches.

No flammable or explosive objects or liquids should be located in the laser area.

This operating manual interprets a selection of accident prevention regulations from the point of view of using laser subsystems in industrial plants. However, the applicable local and national standards, rules and regulations are binding.




Fig. 1
Laser area

2 BASIC INFORMATION

2.1 Introduction

Chapters 1 to 8 of this operating manual describe the general handling of subsystems the following series: AXIALSCAN and FOCUSHIFTER. See the data sheet in the appendix for the different features. For details of the type you are using, refer to the rating plate.

This operating manual contains important information on qualified and safe handling of the subsystem. You should therefore familiarize yourself with the content of this manual before using the subsystem for the first time. In case of any queries, please contact RAYLASE.

The operating manual must be accessible to anyone who will be involved in developing, installing or using a laser device featuring the RAYLASE subsystem. If the subsystem is sold on, this operating manual or an authorized copy must be passed on with it.

2.2 Package contents

Standard:

- Subsystem consisting of linear translator module and deflection unit
- Connecting cable between linear translator module and deflection unit (only digital subsystems)

Optional:


- Protection window
- Control card (only digital subsystems)
- Connecting cable between control card and deflection unit (only digital subsystems)
- Software package (only digital subsystems)

2.3 Module overview

The illustration below shows three typical digital laser devices that are equipped with RAYLASE and customer-specific (indicated by dotted lines) modules.

Analog subsystems are controlled by using an analog current or voltage interface provided by the customer.

Fig. 2
Module overview



2.4 Warranty

The rights of the customer in respect of any defects in quality or deficiencies in title are governed by the general conditions of business of RAYLASE AG. These conditions are available for review on our website.

Pack the product in the original packaging or in packaging that provides equivalent protection for shipping.

RAYLASE shall not be obliged to repair defects under the following circumstances:

- If persons not authorized by RAYLASE have attempted to repair the product.
- If persons not authorized by RAYLASE have modified the product.
- If the product has been used improperly.
- If the product has been connected to incompatible devices.
- If the product has been damaged because of inadmissible high laser power or focusing the laser on optical areas.
- If the product has been damaged because of unqualified cleaning of the optical areas.
- If the warranty period is expired.

Note: No implicit guarantee or warranty of suitability for specific purposes has been made. RAYLASE is not responsible for damages arising from use of the product. Individual assemblies or other assemblies manufactured by RAYLASE may be subject to separate warranty conditions. Refer to the corresponding manuals for further information.

2.5 Manufacturer

RAYLASE AG
Argelsrieder Feld 2+4
82234 Wessling
Germany
Tel.: +49 (0) 81 53 - 88 98 - 0
Fax: +49 (0) 81 53 - 88 98 - 10
<http://www.raylase.de>
E-mail: info@raylase.de

2.6 Customer Service

The RAYLASE support services are available for your problems either in respect to the deflection unit or this manual. Before calling for support, please make sure you refer to any appropriate sections in the manuals on the supplied CD that may answer your questions.

If you need further assistance call RAYLASE customer service department, Monday through Friday between 8 A.M. and 5 P.M. (Middle European Time).

The customer service personnel will be able to give you direct assistance and answers to your questions.

Germany (Wessling)
+49 (0) 81 53 - 88 98 – 0
E-Mail: support@raylase.de

... ask for the customer service department

2.7 Status LED of the linear translator module

The status LEDs allow you to check important functions and statuses on the linear translator module. The LEDs are located behind a protection window on the top of the module.

For subsystems with analog interface only

2.7.1 Analog linear translator modules

LED arrangement	Name	Color	Meaning
	D4	green	Position acknowledge-Z
	D5	green	not used
	D8	red	Error Z
	D9	red	not used
	D10	green	+VCC
	D11	green	-VCC

For subsystems with digital interface only

2.7.2 Digital linear translator modules

LED arrangement	Name	Color	Meaning
	D1	red	CLK error
	D2	red	Parity error Z
	D3	---	not used
	D4	green	Temp. status Z
	D5	---	not used
	D6	orange	New data Z
	D7	---	not used
	D8	red	Error Z
	D9	---	not used
	D10	green	+VCC
	D11	green	-VCC

2.8 Status LEDs of the deflection unit

The status LEDs allow you to check important functions and statuses on the deflection unit. If the deflection unit has status LEDs (depends on the type), they are located behind a protection window on the rear of the deflection unit.

For subsystems with analog interface only

2.8.1 Analog deflection units

LED arrangement	Name	Color	Meaning	
<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; gap: 10px;"> D5 D11 </div> <div style="display: flex; gap: 10px;"> D4 D8 </div> <div style="display: flex; gap: 10px;"> D9 D10 </div> </div>	D4	green	Position acknowledge-X	Data transfer when LEDs are flickering. (not analyzable)
	D5	green	Position acknowledge-Y	
	D8	red	Error X	Galvanometer scanner or driver electronics defective. Power supply defective if LEDs are flickering.
	D9	red	Error Y	
	D10	green	+VCC	Power supplies ready for being used if LEDs are lit.
	D11	green	-VCC	

For subsystems with digital interface only

2.8.2 Digital deflection units

LED arrangement	Name	Color	Meaning	
<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; gap: 10px;"> D3 D7 D11 </div> <div style="display: flex; gap: 10px;"> D1 D5 D9 </div> <div style="display: flex; gap: 10px;"> D2 D4 D8 </div> <div style="display: flex; gap: 10px;"> D6 D10 </div> </div>	D1	red	CLK error	Data transmission faulty. Cable defective.
	D2	red	Parity error X	
	D3	red	Parity error Y	
	D4	green	Temp. status X	Temperature status available if LEDs are lit.
	D5	green	Temp. status Y	
	D6	orange	New data X	New data is being transferred if status LEDs are lit.
	D7	orange	New data Y	
	D8	red	Error X	Galvanometer scanner or driver electronics defective. Power supply defective if LEDs are flickering.
	D9	red	Error Y	
	D10	green	+VCC	Power supplies ready for being used if LEDs are lit.
	D11	green	-VCC	

3 TECHNICAL DATA

This section outlines the common features of all subsystems. For type-specific features, refer to the data sheets in the appendix. The individual data can be assigned using the rating plates on the linear translator module and the deflection unit in conjunction with the identification code (⇒ below, Rating plate code).

3.1 Rating plate code

The following type designation is used in the data sheets in the appendix:

Type designation
 AS AXIALSCAN (subsystem consisting of LTM and deflection unit)
 Beam input aperture of deflection unit (mm)
 Coating
 Min. field size (mm x mm)
 BO = beam optimized
 HP = high power
 HS = high speed
 XX-XX XX [XXX]

Type designation
 FS FOCUSSHIFTER (subsystem consisting of LTM-FS and deflection unit)
 Beam input aperture of deflection unit (mm)
 Coating
 XX-XX [XX]

Both modules – linear translator module and deflection unit – have separate rating plates. Refer to the following sections to identify the modules.

3.1.1 Deflection Unit

type designation	
RL	RL
RL-II	RL-II
RLA	RLA
MS	MINISCAN
SS-II	SUBERSCAN II
SS-II-LD	SUPERSCAN II -LOW DRIFT
SS-II-HS	SUPERSCAN II -HIGH SPEED
SS-II-HS-LD	SUPERSCAN II -HIGH SPEED -LOW DRIFT
SS-II-UHS	SUPERSCAN II -ULTRA HIGH SPEED
SS-II-UHS-LD	SUPERSCAN II -ULTRA HIGH SPEED -LOW DRIFT
SS	SUPERSCAN
SS-SC	SUPERSCAN -SC (special version)
SS-LD	SUPERSCAN -LOW DRIFT
TS	TURBOSCAN
RS-AC	RAZORSCAN -AUTO CALIBRATION
RL-KIT	RL-KIT
RL-II-KIT	RL-II -KIT
RLA-KIT	RLA -KIT
SS-KIT	SUPERSCAN -KIT
TS-KIT	TURBOSCAN -KIT
aperture(mm)	
wavelength	
C	9000nm to 11000nm
AU	10600nm
Y	1064nm
DY	532nm
TY	355nm
AG	400nm to 1064nm
405	405nm
DY+Y	532nm and 1064nm
780-980	780nm to 980nm
780-980+AL	780nm to 980nm and AL
850-870+1064	850nm to 870nm and 1064nm
900-1030+AL	900nm to 1030nm and AL
900-1100+AL	900nm to 1100nm and AL
915-975	915nm to 975nm
975	975nm
975-985+AL	975nm to 985nm and AL
AL	180nm to 700nm
AR	488nm to 514nm
version (optionally)	
interface	
D1	25pol Data/Power
D2	25pol Data/9pol Power
A	Analog
additional or customer no. (optionally)	
XX-XX [XX] Vx XX /X	

Note: The linear translator is provided with its own nameplate.

3.1.2 Linear Translator Module

```

TYPE DESIGNATION
LTM LINEAR TRANSLATOR MODULE

  aperture (mm)
    wavelength
      C 10600nm
      C* 9000-11000nm
      Y 1064nm
      DY 532nm
      TY 355nm
    default field size
      100BO 100mm x 100mm
      250BO 250mm x 250mm
      100 100mm x 100mm
      250 250mm x 250mm
      200HP 200mm x 200mm, MP5-Coating
      600 600mm x 600mm
      300HP 300mm x 300mm, MP5-Coating
      600HP 600mm x 600mm, MP5-Coating
    extra (optionally)
      -SR anti reflex coating
      -HP MP5-Coating
      -HS HIGH SPEED
    version (optionally)
      V2 mono block version
    interface
      D2 25pol Date / 9pol Power / 25pol Data/Power
      A Analog
    additional or customer no. (optionally)

LTM-XX X [XXX] Vx X /X
    
```

Note: The defection unit is provided with its own nameplate.

3.1.3 Linear Translator Module (FOCUSSHIFTER)

```

TYPE DESIGNATION
LTM-FS LINEAR TRANSLATOR MODULE FOR FOCUSSHIFER

  amplification factor
  Lx Beam Expansion Factor x

  aperture
    wavelength
      Y 1064nm
      DY 532nm
      TY 355nm
      C 10600nm
    tuning (optionally)
      S step tuning
      V vector tuning
    version (optionally)
      V2 mono block version
    interface
      D2 25pol Date / 9pol Power / 25pol Data/Power
    additional or customer no. (optionally)

LTM-FS Lx XX [X] X Vx X /X
    
```

Note: The defection unit is provided with its own nameplate.

3.2 Conformity with directives

The subsystem conforms to the requirements of the following directives:

- EU Directive 89/336/EEC or German law on electromagnetic compatibility (EMVG)
- EU Directive 2002/95/EC or German law on electrical equipment (ElektroG)

For details of conformity with other directives, contact RAYLASE.

4 FUNCTIONAL DESCRIPTION

4.1 Laser beam subsystem

The laser beam subsystem consists of the deflection unit and the linear translator module. The deflection unit can be used to deflect a laser beam in X and Y directions. This results in a two-dimensional plane, within which a laser can be directed at any position. This area is known as the "operating field" and is shown in Fig. 3 and Fig. 4. Deflection is performed by two mirrors, each of which is moved by a galvanometer scanner. RAYLASE provides the appropriate deflection unit for the deflection properties required. The laser beam subsystem can therefore be fitted with different deflection units. Refer to the rating plate to identify the deflection unit used (⇒ page 13, Rating plate code).

The focusing properties of the laser beam subsystem are determined by the linear translator module and, on some versions, also by an F-Theta lens on the deflection unit. The linear translator module is fitted with one or two focusing lenses. An additional lens with linear movement allows the focusing length to be adjusted.

Because of their different focusing properties, the subsystems are divided into four groups:

AXIALSCAN (standard)

In these systems, the lens with linear movement is moved within a small range by a galvanometer unit. This so-called linear translator allows the focusing length to be adjusted to the relevant deflection angle of the deflection unit. Compared to an F-Theta lens, this provides a relatively large operating field, in which the laser beam can be optimally focused at every point. The size of the operating field is set manually during installation (⇒ page 42, Manually adjusting the field size). The optical system and the electronic components of the deflection unit can be protected against contamination by installing a protection window over the beam output (⇒ page 24, Protection window).

AXIALSCAN (water cooled)

Like the standard AXIALSCAN, the water cooled version is also fitted with a motorized adjustable lens. Unlike the standard version, the lens is moved using two galvanometer units to increase the speed.

As well as this version designed for high speed, a version designed for a high laser power is available.

AXIALSCAN (motorized)

On this version of the AXIALSCAN, the entire linear translator can be moved by a motor. This enables motorized adjustment of the size of the operating field (⇒ page 5, Motorized field size adjustment).

FOCUSHIFTER (standard)


On the FOCUSHIFTER, an F-Theta lens on the deflection unit is used for focusing and to set the size of the operating field. With this configuration, the linear translator module can be used to change the focusing plane. This allows almost three-dimensional operations to be performed. For example, this is useful when creating a 3D image in a glass block or for deep processing of materials.

Subsystems are available as analog or digital versions. Refer to the following functional principles.

For subsystems with analog interface only

4.2 Functional principle of analog subsystems

Fig. 3
Functional
principle of ana-
log subsystems



- | | |
|---------------------------------------------------------------------|-----------------------------------------------|
| 1 Linear translator module | 8 Beam output |
| 2 Beam input | 9 Operating field |
| 3 Lens with linear movement | 10 Power supply of linear translator module |
| 4 Focusing lens (or 2x, depending on model) | 11 Analog input of linear translator module |
| 5 Spacer (depends on model) with mounting plate for deflection unit | 12 Stepper motor interface (depends on model) |
| 6 Deflection unit | 13 Analog input of deflection unit |
| 7 Galvanometer scanner with mirror | 14 Power supply of deflection unit |

For subsystems with digital interface only

4.3 Functional principle of digital subsystems





Fig. 4
AXIALSCAN
(standard)

AXIALSCAN
(motorized)

- | | |
|---------------------------------------------------------------------|-----------------------------------------------|
| 1 Linear translator module | 9 Operating field |
| 2 Beam input | 10 Digital input |
| 3 Lens with linear movement | 11 Power supply |
| 4 Focusing lens (or 2x, depending on model) | 12 Digital output |
| 5 Spacer (depends on model) with mounting plate for deflection unit | 13 Connecting cable |
| 6 Deflection unit | 14 Stepper motor interface (depends on model) |
| 7 Galvanometer scanner with mirror | 15 Digital interface of deflection unit |
| 8 Beam output | |

Fig. 5
AXIALSCAN
(water-cooled)



- | | |
|---------------------------------------------------------------------|---------------------------------------------|
| 1 Linear translator module | 9 Operating field |
| 2 Beam input | 10 Power supply of linear translator module |
| 3 Lens with linear movement | 11 Digital Input |
| 4 Focusing lens (or 2x, depending on model) | 12 Digital Output |
| 5 Spacer (depends on model) with mounting plate for deflection unit | 13 Connecting cable |
| 6 Deflection unit | 14 Output coolant |
| 7 Galvanometer scanner with mirror | 15 Digital interface of deflection unit |
| 8 Beam output | 16 Input coolant |

Important information:

When connecting the water cooling, make sure that no coolant gets into the subsystem. The units are not waterproof and liquids can damage both the optical system and the electronics.





Fig. 6
FOCUSHIFTER
(standard)

- | | |
|---------------------------------------------|-----------------------------------------|
| 1 Linear translator module | 9 Digital output |
| 2 Beam input | 10 Power supply |
| 3 Lens with linear movement | 11 Digital input |
| 4 Focusing lens (or 2x, depending on model) | 12 Connecting cable |
| 5 Deflection unit | 13 Digital interface of deflection unit |
| 6 Beam output with F-Theta lens | |
| 7 Operating field | |
| 8 Galvanometer scanner with mirror | |


Fig. 7
Linear translator
module from
AXIALSCAN
(standard) sub-
system



1 Linear translator

2 Focusing lens

Fig. 8
Linear translator
module from
AXIALSCAN
(motorized) sub-
system



1 Linear translator

2 Motorized field size adjustment

3 SENSOR LEFT

4 SENSOR CENTER

5 SENSOR RIGHT

6 Focusing lens





Fig. 9
 Linear translator
 module of sub-
 system:
 AXIALSCAN
 (water-cooled)

- | | |
|------------------------------------------|-------------------------------------------|
| 1 Linear translator | 3 Focusing lens |
| 2 Clamping screw (field size adjustment) | 4 Adjusting screw (field size adjustment) |

For subsystems fitted with a protection window only

4.4 Protection window

Fig. 10
Protection win-
dow



Installation instructions

- Before installation, check the protection window for dirt, scratches or cracks.
 - If the protection window is dirty, it must be cleaned (⇒ page 47, Instructions for cleaning F-Theta lenses and protection windows).
 - If the protection window is scratched or cracked, it must be replaced.
- Screw the protection window and mount into the beam output on the deflection unit until it is positioned securely.

For subsystems fitted with an F-Theta lens only

4.5 F-Theta lens

The F-Theta lens is specially designed for use with 2-axis deflection units or in FOCUSHIFTER 3-axis subsystems. It focuses the laser beam at optimum quality on any position in the operating field. At the same time, it provides partial optical compensation for the barrel-shaped distortion that is unavoidable when using a 2-axis deflection unit. The remaining distortion (see below) must be compensated by the deflection unit drive.




Fig. 11
Field distortion with and without F-Theta lens




Fig. 12
Example:
F-Theta lens for Nd:YAG

Installation instructions


- Before installation, check the lens and the protection window for dirt, scratches or cracks.
 - If the optical system is dirty, it must be cleaned (⇒ page 47, Instructions for cleaning F-Theta lenses and protection windows).
 - A scratched or cracked lens and/or protection window must be replaced. If necessary, the protection window can be replaced separately.
- Screw the lens into the beam output on the deflection unit until it is positioned securely.

4.6 Interfaces of the linear translator module

For subsystems with analog interface only

4.6.1 Analog input


The terminal assignment of the analog interface is outlined below. To determine whether the deflection unit is fitted with an analog or a digital interface, refer to the code on the rating plate (⇒ page 13, Rating plate code).

	PIN	Signal	PIN	Signal
 <p>25 PIN D-SUB</p>	1	GND	14	nu
	2	GND	15	nu
	3	GND	16	nu
	4	GND	17	nu
	5	nu	18	nu
	6	GND	19	nu
	7	GND	20	-Z Command
	8	GND	21	+Z Command
	9	GND	22	Z Position
	10	GND	23	/Z Temp-ok
	11	/Z Ready	24	/Z Pos-Error
	12	GND	25	Z Velocity
	13	GND	---	---

nu = not used

Fig. 13
Signal input


To prevent errors, shielded cables should be used and signals must be input as shown below.



For subsystems with digital interface only

4.6.2 Digital input

The linear translator module is connected to a RAYLASE control card using the 25-pin D-SUB connector. All signals are compatible with RAYLASE's extended function XY2-100 standard.

	PIN	Signal	PIN	Signal
 25 PIN D-SUB	1	I -SENDCLOCK	14	I +SENDCLOCK
	2	I -SYNC	15	I +SYNC
	3	I -X-DAC CHANNEL	16	I +X-DAC CHANNEL
	4	I -Y-DAC CHANNEL	17	I +Y-DAC CHANNEL
	5	I -Z-DAC CHANNEL	18	I +Z-DAC CHANNEL
	6	O -HEAD-STATUS	19	O +HEAD-STATUS
	7	nc	20	nc
	8	nc	21	nc
	9	nc	22	nc
	10	nc	23	GND
	11	GND	24	GND
	12	nc	25	nc
	13	nc	---	---


I = Diff. Input, nc = not connected, O = Diff. Output

Specifications

Diff. Input-, Diff. Input+		Diff. Output-, Diff. Output+		
Input voltage	5V	Output low	max. 0.6V	max. 40mA
Input threshold	200mV	Output high	min. 2V @ 50Ω	max. 40mA
Hysteresis	typ. 45mV	ESD protection	±10kV	
Input impedance	120Ω			
ESD protection	±15kV			

4.6.3 Power supply


The 9-pin D-SUB connector provides the linear translator module with power. The power supply must be provided by the OEM customer. Refer to the following connection and parameter table:

	PIN	Designation	PIN	Designation
 9 PIN D-SUB	1	-VSS	6	-VSS
	2	-VSS	7	GND
	3	GND	8	GND
	4	+VSS	9	+VSS
	5	+VSS	---	---

For subsystems fitted with motorized field size adjustment only

4.6.4 Stepper motor interface

The 15-pin D-SUB male connector is used to operate the stepper motor for motorized field size adjustment.

	PIN	Signal	PIN	Signal
 15 PIN D-SUB	1	I -Motor W3 (yellow)	9	I +Motor W3 (black)
	2	I -Motor W1 (brown)	10	I +Motor W1 (red)
	3	I -Motor W4 (purple)	11	I +Motor W4 (blue)
	4	I -Motor W2 (green)	12	I +Motor W2 (white)
	5	nc	13	nc
	6	O SENSOR CENTER	14	O SENSOR LEFT
	7	O SENSOR RIGHT	15	I GND
	8	I VSS (+24V)	---	

I = Input, nc = not connected, O = Output

Specifications

Sensor Output	
Output high	VSS - ($\leq 3V$)
Current low	max. 50mA
Current high	max. 100mA

Stepper motor and sensors





Fig. 14
Stepper motor and sensors, schematic view

Manufacturer: Phytron

For subsystems with digital interface only

4.6.5 Digital output

The linear translator module uses the 25-pin D-SUB female connector to transmit data to the deflection unit and supply it with power. All signals are compatible with RAYLASE's extended function XY2-100 standard.

	PIN	Signal	PIN	Signal
 <p>25 PIN D-SUB</p>	1	O -SENDCLOCK	14	O +SENDCLOCK
	2	O -SYNC	15	O +SYNC
	3	O -X-DAC CHANNEL	16	O +X-DAC CHANNEL
	4	O -Y-DAC CHANNEL	17	O +Y-DAC CHANNEL
	5	nc	18	nc
	6	I -HEAD-STATUS	19	I +HEAD-STATUS
	7	nc	20	nc
	8	nc	21	nc
	9	+VSS	22	+VSS
	10	+VSS	23	GND
	11	GND	24	GND
	12	-VSS	25	-VSS
	13	-VSS	---	---

I = Diff. Input, nc = not connected, O = Diff. Output

Specifications

Diff. Input-, Diff. Input+	
Input voltage	5V
Input threshold	200mV
Hysteresis	typ. 45mV
Input impedance	120Ω
ESD protection	±15kV


Diff. Output-, Diff. Output+		
Output low	max. 0.6V	max. 40mA
Output high	min. 2V @ 50Ω	max. 40mA
ESD protection	±10kV	

4.7 Interfaces of the deflection unit

For subsystems with analog interface only


4.7.1 Analog input

The terminal assignment of the analog interface is outlined below. To determine whether the deflection unit is fitted with an analog or a digital interface, refer to the code on the rating plate (⇒ page 13, Rating plate code).

	PIN	Signal	PIN	Signal
 25 PIN D-SUB	1	GND	14	-Y Command
	2	GND	15	+Y Command
	3	GND	16	Y Position
	4	GND	17	/Y Temp ok
	5	/Y Ready	18	Y Pos Error
	6	GND	19	Y Velocity
	7	GND	20	-X Command
	8	GND	21	+X Command
	9	GND	22	X Position
	10	GND	23	/X Temp ok
	11	/X Ready	24	/X Pos Error
	12	GND	25	X Velocity
	13	GND	---	---

To prevent errors, shielded cables should be used and signals must be input as shown below.


Fig. 15 Signal input



For subsystems with analog interface only

4.7.2 Power supply


The 9-pin D-SUB connector provides the deflection unit with power. The power supply must be provided by the OEM customer. Refer to the following connection and parameter table:

	PIN	Designation	PIN	Designation
 9 PIN D-SUB	1	-VSS	6	-VSS
	2	-VSS	7	GND
	3	GND	8	GND
	4	+VSS	9	+VSS
	5	+VSS	---	---

For subsystems with digital interface only

4.7.3 Digital interface

The deflection unit uses the 25-pin D-SUB female connector to receive signals and its power supply from the linear translator module. All signals are compatible with RAYLASE's extended function XY2-100 standard. Refer to the following connection table:

	PIN	Signal	PIN	Signal
 25 PIN D-SUB	1	I -SENDCLOCK	14	I +SENDCLOCK
	2	I -SYNC	15	I +SYNC
	3	I -X-DAC CHANNEL	16	I +X-DAC CHANNEL
	4	I -Y-DAC CHANNEL	17	I +Y-DAC CHANNEL
	5	nc	18	nc
	6	O -HEAD-STATUS	19	O +HEAD-STATUS
	7	I -P-DAC CHANNEL	20	I +P-DAC CHANNEL
	8	nc	21	nc
	9	+VSS	22	+VSS
	10	+VSS	23	GND
	11	GND	24	GND
	12	-VSS	25	-VSS
	13	-VSS	---	---

I = Diff. Input, nc = not connected, O = Diff. Output

Specifications

Diff. input-, Diff. input+		Diff. output-, Diff. output+	
Input voltage	5V	Output low	max. 0.6V max. 40mA
Input threshold	200mV	Output high	min. 2V @ 50Ω max. 40mA
Hysteresis	typ. 45mV	ESD protection	±10kV
Input impedance	120Ω		
ESD protection	±15kV		

5 INSTALLATION

The following sections describe installation of the subsystem in a laser device. When doing this, it is essential to check that the laser beam is input into the linear translator module and output from the module centrally. Otherwise, misalignment of the laser beam will occur each time the focus is changed. The linear translator module and the deflection unit are calibrated to one another prior to delivery and do not need to be adjusted.



Warning:

- The laser beam can cause severe injury to the eyes and the skin. Note that even apparently matt objects can reflect the wavelength of laser beams. All personnel in the room must wear appropriate laser protection goggles and, if necessary, protective clothing.
- Never look directly at the laser beam, even when wearing protective goggles.
- The subsystem may require the laser device to be assigned to a different danger class (⇒ page 6, Classification of laser devices).
- The laser must be switched off during installation.
- We recommend that the laser area is completely protected by an appropriate working chamber. If this is not possible, appropriate protective measures for the laser class must be implemented.
- The mirrors in the deflection unit must move freely after installation of the deflection unit. No components of the laser device may protrude into the deflection unit.
- The laser device must be of sufficient quality that the laser beam can only be emitted at the beam output on the deflection unit.
- The "Laser radiation" accident prevention regulations (BGV B2) must be observed.
- Connecting cables may not be subjected to mechanical strain.
- The subsystem must be protected against moisture, dust and corrosive vapors.
- The optical components may only be touched when wearing unpowdered latex gloves.
- The subsystem must be protected against static discharge and strong electromagnetic fields.
- The power density of the input laser radiation may not exceed the maximum permissible power density of the optical components in the subsystem.
- The beam path and the function of the subsystem must be tested after installation.
We recommend performing all tests with a danger class 1 or 2 laser to minimize the risk of injury. If this is not possible, the laser used must be set to the lowest possible power. This setting must be secured against accidental adjustment.

5.1 Installing the linear translator module

- Carefully remove the protective cover over the beam input with a small screwdriver.
- To install the subsystem, insert locating pins into the corresponding holes and attach the subsystem to the prepared installation surface using screws.

Note: The subsystem may only be installed using the pins and screws specified by RAYLASE. Follow the installation drawing supplied.

5.2 Checking the beam coupling: AXIALSCAN (Standard), AXIALSCAN (motorized), FOCUSSHIFTER (Standard)

5.2.1 Preparation


In order to be able to check the beam coupling, all components located in the beam path must be removed and the deflection unit dismantled. The process for doing this is as follows:

Fig. 16
Preparing the
beam coupling

AXIALSCAN
(standard)

AXIALSCAN
(motorized)

FOCUSHIFTER
(standard)



- Remove the following components in turn:
 - Connecting cable between linear translator module and deflection unit
 - Linear translator module cover (1).
- Mark the installation position of the focusing lens (2) or the two focusing lenses for re-installation.
- Remove the following components in turn:
 - Focusing lens and second focusing lens if fitted.
 - Deflection unit (4); in subsystems with spacer: Only dismantle the deflection unit, not the spacer (3) and the mounting plate for the deflection unit.
 - Linear translator, (5) or (6) depending on model.
- Protect the focusing lens, deflection unit and linear translator against dust.

5.2.2 Checking procedure

The following steps are used to check that the laser beam is input into the linear translator module and output from the module centrally. If this is not the case, the input point and, if necessary, the input angle of the laser beam must be adjusted as described below.



Warning:

The laser beam can cause severe injury to the eyes and the skin. Make sure that all personnel in the laser area are wearing appropriate protective goggles and, if necessary, protective clothing.




Fig. 17
Checking the beam coupling

AXIALSCAN
(standard)

AXIALSCAN
(motorized)

FOCUSHIFTER
(standard)

Checking the input point

- Insert the cross hair device into the beam input (1).
- Hold a piece of thermo transfer paper behind the cross hair device.
- Turn on the laser at low power for just long enough for a clearly visible effect to appear on the thermo transfer paper (3).
- Check the beam diameter. It must be smaller than the input aperture specified in the data sheet.
- Check that the laser beam appears in the center of the cross hairs. If not, the input point of the laser beam needs to be adjusted.

Checking the input angle

- Insert the cross hair device into the beam output (2). In subsystems with spacer: Insert the cross hair device into the opening in the mounting plate.
- Hold a piece of thermo transfer paper behind the cross hair device.
- Turn on the laser at low power for just long enough for a clearly visible effect to appear on the thermo transfer paper.
- Check the beam diameter. It must be smaller than the input aperture specified in the data sheet. If the beam diameter at the beam output is greater than that measured at the beam input, this indicates excessive divergence of the laser beam. In this case, reduce the beam diameter, e. g. by using beam expander with lower amplification.
- Check that the laser beam appears in the center of the cross hairs. If not, the input angle of the laser beam needs to be adjusted.

Optimizing settings

- Repeat the entire adjustment process until optimum laser beam input point and input angle settings are achieved.

5.2.3 Assembly

The process for assembling all of the components is as follows:


Fig. 18

Finalize the checking procedure

AXIALSCAN
(standard)

AXIALSCAN
(motorized)

FOCUSHIFTER
(standard)



- Install the deflection unit (4).
- Install the focusing lens(es) (2). Pay attention to the corresponding markings.
- Install the linear translator, (5) or (6) depending on the model.
- If you are using a subsystem with manual field size adjustment, you now have to adjust the field size (⇒ page 42, Manually adjusting the field size). In subsystems with motorized field size adjustment, this is done by the software.
- Fit the cover (1).

5.3 Checking the beam coupling: AXIALSCAN (water cooled)

5.3.1 Preparation

In order to be able to check the beam coupling, all components located in the beam path must be removed and the deflection unit dismantled. The process for doing this is as follows:




Fig. 19
Preparing the
beam coupling

AXIALSCAN
(water cooled)

- Remove the following components in turn:
 - Connection cable between linear translator module and deflection unit.
 - Hose connections for water cooling.
 - Important information:**
Make sure that no coolant gets into the subsystem. The units are not waterproof and liquids can damage both the optical system and the electronics.
 - Linear translator module cover (1).
- Remove the following components in turn:
 - Focusing lens (3).
 - Deflection unit (5);
in sub systems with spacer: Only dismantle the deflection unit, not the spacer (4) and the mounting plate for the deflection unit.
 - Linear translator (2).
- Protect the focusing lens, deflection unit and linear translator against dust.

5.3.2 Checking procedure

The following steps are used to check that the laser beam is input into the linear translator module and output from the module centrally. If this is not the case, the input point and, if necessary, the input angle of the laser beam must be adjusted as described below.




Warning:

The laser beam can cause severe injury to the eyes and the skin. Make sure that all personnel in the laser area are wearing appropriate protective goggles and, if necessary, protective clothing.

Fig. 20
Checking the
beam coupling

AXIALSCAN
(water cooled)



Checking the input point

- Insert the cross hair device into the beam input (1).
- Hold a piece of thermo transfer paper behind the cross hair device.
- Turn on the laser at low power for just long enough for a clearly visible effect (3) to appear on the thermo transfer paper.
- Check the beam diameter. It must be smaller than the input aperture specified in the data sheet.
- Check that the laser beam appears in the center of the cross hairs. If not, the input point of the laser beam needs to be adjusted.

Checking the input angle

- Insert the cross hair device (2) into the beam output and repeat the above steps in this position.
In subsystems with a spacer, insert the cross hair device in the mounting plate.
- Hold a piece of thermo transfer paper behind the cross hair device.
- Turn on the laser at low power for just long enough for a clearly visible effect to appear on the thermo transfer paper.
- Check the beam diameter. It must be smaller than the input aperture specified in the data sheet. If the beam diameter at the beam output is greater than that measured at the beam

input, this indicates excessive divergence of the laser beam. In this case, reduce the beam diameter, e.g. by using beam divergence with lower amplification.

- Check that the laser beam appears in the center of the cross hairs. If not, the input angle of the laser beam needs to be adjusted on the laser.

Optimizing settings

- Repeat the entire adjustment process until optimum laser beam input point and input angle settings are achieved.

5.3.3 Assembly

The process for assembling all of the components is as follows:




Fig. 21
Ending the
checking pro-
cedure

AXIALSCAN
(water cooled)

- Install the deflection unit (5).
- Install the focusing lens (3). Pay attention to the corresponding markings.
- Install the linear translator (2).
- Adjust the field size (⇒ page 42, Manually adjusting the field size).
- Fit the cover (1).

For subsystems with manual field size adjustment only

5.4 Manually adjusting the field size

The 3-axis laser beam subsystem can be adjusted to different field sizes as follows. The field sizes that can be set are listed in the data sheet. If you want to set a different field size, you must consult RAYLASE for assistance.

5.4.1 Preparation

- o Load the correction file corresponding to the desired operating field size.
Make sure that you use the following identification code:

AXIALSCAN

The following identification code is used for AXIALSCAN type subsystems:

```

Type
AS AXIALSCAN
  Aperture of associated deflection unit [mm]
  Coating code      Wavelength [nm] ..... Laser
  DY                532 ..... Nd:YAG
  TY                355 ..... Nd:YAG
  Y                 1064 ..... Nd:YAG
  C                 10600 ..... CO2
  Field size range (min.-max.)
  Type
  st standard
  bo beam optimized
  hp high power
  Operating field size
  L
XX-XX-XX_XXXX-XXXXxxx_XXXX.gcd

```

FOCUSSHIFTER¹

The following identification code is used for FOCUSSHIFTER type subsystems:

```

Type
FS FOCUSSHIFTER
  Aperture of associated deflection unit [mm]
  Coating code      Wavelength [nm] ..... Laser
  DY                532 ..... Nd:YAG
  TY                355 ..... Nd:YAG
  Y                 1064 ..... Nd:YAG
  C                 10600 ..... CO2
  Focal distance
  L
XX-XX-XX_XXX.gcd

```

- o Create all electrical connections for the power supply and for control of the 3-axis subsystem (⇒ page 17, Laser beam subsystem).
- o For details of connecting the deflection unit to a RAYLASE control card and operation with RAYLASE software, refer to the corresponding manuals.

¹ In general there are no special correction files for Focusshifter. The standard 2-axis correction files are used. For using weldMARK in combination with FOCUSSHIFTER a special configuration file has to be generated in order to compensate for different object sizes at different z-position.

5.4.2 Adjustment procedure:: AXIALSCAN (standard)




Fig. 22
Manual field size
adjustment

AXIALSCAN
(standard)

- Loosen the two retaining screws (1).
- Move the linear translator to the distance (D) specified in the reference table in the appendix. As shown above, the distance (D) is measured from the front edge of the linear translator to the inner side of the housing plate.
- Lightly screw in the linear translator at the set position.

Fine adjustment

Fine adjustment is used to adjust the linear translator to the laser-specific divergence.



Warning:


The laser beam can cause severe injury to the eyes and the skin. Make sure that all personnel in the laser area are wearing appropriate protective goggles and, if necessary, protective clothing.

- Place a target of the same size as the operating field at the specified working distance from the deflection unit.
- In turn, use the laser to mark a square in the center of the field and at one corner.
- Check that the spot diameter is the same in the center of the field and at the corner.
- If necessary, move the linear translator within the range provided by the slots and repeat the fine adjustment until a satisfactory result is obtained in the center of the field and at the corner.
- Fix the linear translator in place with the two fastening screws (1).

5.4.3 Adjustment procedure: AXIALSCAN (water cooled)

Fig. 23
Manual field
size adjustment

AXIALSCAN
(water cooled)



- | | |
|---------------------|-------------------|
| 1 Linear translator | 3 Focusing lens |
| 2 Clamping screw | 4 Adjusting screw |

- Release the clamping screw (2).
- Move the linear translator (1) using the adjusting screw (4) until the required setting is approximately reached. The positions for the approximate setting are indicated by a sticker attached on the inside, which can be seen when the cover is open.

Fine adjustment

Fine adjustment is used to adjust the linear translator to the laser-specific divergence.



Warning:

The laser beam can cause severe injury to the eyes and the skin. Make sure that all personnel in the laser area are wearing appropriate protective goggles and, if necessary, protective clothing.

- Place a marker the same size as the operating field at the specified working distance from the deflection unit.
- In turn, use the laser to mark a square in the center of the field and at one corner.
- Check that the spot diameter is the same in the center of the field and at the corner.
- If necessary, move the linear translator using the adjusting screw (4) and repeat the fine adjustment until a satisfactory result is obtained in the center of the field and at the corner.
- Fix the linear translator in place with the clamping screw (2).

For subsystems with motorized field size adjustment only

5.5 Motorized field size adjustment

The 3-axis laser beam subsystem can be adjusted to different field sizes using the motor: With motorized field size adjustment, the software adjusts the optical components.

6 CLEANING

6.1 Cleaning the housing



Warning:

The laser beam can cause severe injury to the eyes and the skin. Before cleaning, make sure that the laser device is switched off and secured against accidentally being switched on.

The subsystem housing is dust proof. It can be cleaned with a duster. If it is very dirty, the duster can be moistened with a light and non-aggressive cleaning solution (e.g. soap solution).

6.2 Cleaning the optical system



Warning:

The laser beam can cause severe injury to the eyes and the skin. Before cleaning, make sure that the laser device is switched off and secured against accidentally being switched on.

Dirty optical surfaces result in increased absorption of the laser radiation. This can cause the dirt to heat up sufficiently for it to burn into the optical surfaces and permanently damage them.

The following circumstances can cause increased accumulation of dirt:

- The ambient atmosphere is contaminated with dirt, grease or other particles.
- Vapors and particles are produced while working.
- Talking, coughing or sneezing close to optical surfaces.

In general, all contamination of the optical system should be avoided wherever possible. However, as contamination cannot be completely avoided, the optical system must be cleaned at appropriate intervals. Regular checking and cleaning of the optical surfaces can prevent permanent damage.

Note: RAYLASE accepts no liability for damaged optical components!

Note: Damage caused during the laser process, e.g. when processing metals, is irreversible and cannot be resolved by cleaning.

For subsystems fitted with an F-Theta lens or a protection window only

6.2.1 Instructions for cleaning F-Theta lenses and protection windows



Warning:

The laser beam can cause severe injury to the eyes and the skin. Before cleaning, make sure that the laser device is switched off and secured against accidentally being switched on.

Fingerprints contain aggressive substances that can damage the optical surfaces. Optical surfaces should therefore only be touched when wearing suitable gloves or with a lens cleaning cloth.

- Only touch the optical elements when wearing unpowdered latex gloves and only touch the edges.
- Blow loose particles from the surface with clean and oil-free compressed air. Note that the compressed air in workshops can contain oil particles and is therefore unsuitable for cleaning the optical system.
- Moisten a suitable lens cleaning cloth with ethanol suitable for cleaning optical components.
- Place one end of the moistened cloth on the optical system and slowly move it over the optical components. Do not exert any pressure and do not rub the optical components.
- Remove any remaining ethanol residue with a dry optical cloth.
- Repeat the procedure until the surface is completely clean. Use a new cleaning cloth for each repetition.

6.2.2 Instructions for cleaning focusing lenses and mirrors



Warning:

The laser beam can cause severe injury to the eyes and the skin. Before cleaning, make sure that the laser device is switched off and secured against accidentally being switched on.

The optical surfaces are extremely sensitive and may only be cleaned by experienced personnel.

The procedure for cleaning the focusing lenses in the linear translator module is as follows:

- Mark the installation position of the focusing lens to be cleaned to allow easy re-installation.
- Remove the focusing lens from the linear translator module.
- Clean the focusing lens as described above (⇒ above, Instructions for cleaning F-Theta lenses and protection windows).
- We recommend leaving the lens in the lens holder during cleaning. However, if you do remove the lens from its holder, when replacing it make sure that the lens is precisely positioned in the guide on the holder and refer to the data sheet for the specified direction for the focusing lens. Close the lens holder with a torque wrench with a maximum force of 15 cNm.
- Install the lens holder in the linear translator module. Pay attention to the corresponding markings.

For cleaning the mirrors and the moving lens, we strongly recommend sending the subsystem to RAYLASE, as opening of the deflection unit or dismantling of the moving lens by unauthorized personnel voids the warranty.

However, if you do want to clean the mirrors yourself, follow the same procedure as for cleaning the protection window but with even more care (⇒ oben, Instructions for cleaning F-Theta lenses and protection windows).

6.2.3 Special instructions for zinc selenide optical elements

Zinc selenide (ZnSe) is an inorganic orange material that can be used in different forms for optical components (e.g. lenses, beam splitters, mirrors) in CO₂ laser systems.

Properties of zinc selenide

Melting point:	1,520°C
Density:	5.27g/cm ³ at 25°C
Solubility:	Sensitive to water

To improve the optical properties of the material, zinc selenide is often given an anti-reflex coating that can contain thorium fluoride. Thorium is a α emitter and is slightly radioactive. Thorium is potentially hazardous to health if it is inhaled or swallowed. As the coating containing thorium is enclosed between non-radioactive layers, there is no risk to the user under normal circumstances.

Damage to zinc selenide optical elements

Under normal circumstances, no special precautions are necessary when handling or storing zinc selenide.

In case of damage to a zinc selenide optical element or its anti-reflex coating, follow the instructions below.

Damage to anti-reflex coating

- Possible causes:
 - Coating coming into contact with water, acids or alkalis
 - Mechanical damage due to improper cleaning or handling
- Action:
 - Pack the optical elements in an airtight sealed plastic container.
 - Return the container to your supplier. The supplier is responsible for professional disposal of the material.

Damage to optical element

- Possible causes:
 - Optical element coming into contact with water, acid or alkali
 - Mechanical damage due to improper cleaning or handling
- Action:
 - Avoid inhaling dust!
 - Carefully collect up fragments and pack them in an airtight sealed plastic container.
 - Return the container to your supplier. The supplier is responsible for professional disposal of the material.

Damage to optical element due to laser radiation

- Cause:
 - Damage to optical element due to laser radiation (laser radiation is no longer completely transmitted but is absorbed into the element due to damage to the anti-reflex coating or contamination of the optical element)
- Action:
 - Switch off the laser device immediately!
 - Leave the room for at least 30 minutes!
 - Wear gloves and a mouth protector while performing the subsequent steps!
 - Carefully collect up all fragments and pack them in an airtight sealed plastic container.

- Clean all contaminated components and surfaces with a damp cloth and pack the cleaning cloths in a sealed plastic container.
- Return the containers to your supplier. The supplier is responsible for professional disposal of the material.

Warning: Because of the risks outlined, zinc selenide optical elements must be cleaned with special care and is performed entirely at your own risk!

7 MAINTENANCE

Repairs may only be carried out by RAYLASE or RAYLASE Certified Service Centres as special know-how and comprehensive testing methods are required.

Certified Service Centres:

Russia

Laser Technology Centre
Politechnicheskaya 29
195251 St.Petersburg, Russia

Phone: +7 (812) 552 72 61

Fax: +7 (812) 535 46 98

E-mail: sales@ltc.ru

Web: www.ltc.ru

Turkey

ISSE ULUSLARARASI TICARET ve DANISMANLIK LTD. STI.

Ikitelli O.S.B. Sefaköy San. Sit. 4.

Blok No: 1 Küçükçekmece

Istanbul, Turkey

Phone: +90 212 671 15 64

Fax: +90 212 671 21 64

E-mail: info@lasersos.com.tr

Web: www.lasersos.com.tr

China

RAYLASE Laser Technology (Shenzhen) Co., Ltd 5th Floor, No.6 Qiancheng Road Henggang
228 Industrial Park Longgang District, Shenzhen
518115 Guangdong
China

Phone: +86-(0)755-8222 8324

Fax: +86-(0)755-8222 8193

E-mail: info@raylase.cn

Web: www.raylase.cn

Brazil

ReB Laser Comercial Serviços Ltda.

Rua Eula Herper Bowden, 82

09629-100 - Rudge Ramos

São Bernardo do Campo - SP

Phone: +55(11) 4368-7976 - +55(11) 4368-5053

Fax: +55(11) 4365-4572

E-mail: tecnica@reblaser.com.br

Web: www.reblaser.com.br

8 TROUBLESHOOTING



Warning:

The laser beam can cause severe injury to the eyes and the skin.

- Never look directly or indirectly into the laser beam during troubleshooting.
- Do not disable any safety precautions to protect against laser radiation.
- Wear protective clothing and/or goggles appropriate for the relevant laser class.

In case of malfunctions, check whether the symptom and a possible remedy are included in the following checklist.

Problem	Possible cause and remedy	
Poor marking quality	Defective power supply	
	Incorrect marking parameters	
Marking quality has deteriorated	Dirty optical system	⇒ page 47, Instructions for cleaning F-Theta lenses and protection windows
		⇒ page 47, Instructions for cleaning focusing lenses and mirrors
	Laser power decreasing	The RAYLASE weldMARK™ marking software can compensate for a loss of laser power. Menu: System > Global adjustments
	Marking parameters changed	
Beam expander changed		
Laser spot changed	Dirty optical system	⇒ page 47, Instructions for cleaning F-Theta lenses and protection windows
		⇒ page 47, Instructions for cleaning focusing lenses and mirrors
	Dirty or damaged mirrors	Send deflection unit in for repair
Laser system out of adjustment		
No laser beam, although process started from PC.	Beam path blocked.	Remove protective cover from beam input and/or output
	Fault in laser drive	
	Fault in laser system	
The deflection unit only deflects the laser beam in one direction or not at all.	Data cable defective	⇒ page 11, Status LED of the linear translator module
X and Y axis reversed	Incorrect cabling	

If the fault cannot be resolved, contact RAYLASE Customer Service for further assistance.

INDEX

A	
Adjusting the field size	42
Analog input	
Deflection unit	31
Linear translator module	26

C	
CE symbol	5
Classification of laser devices	6
Cleaning	46
Conformity with directives.....	16
Customer Service.....	10
Customer Support	10

D	
Digital input	
Deflection unit	33
Linear translator module	27
Digital interface.....	26, 31
Digital output	
Linear translator module	30

E	
Earth symbol	5

F	
Functional description.....	17

I	
Identification code	13
Installation	34, 35

L	
Laser area	7

Laser beam subsystem.....	17
Laser safety	5

M	
Maintenance	50
Manufacturer	10
Module overview.....	9

P	
Package contents	8
Power supply	
Deflection unit	32
Linear translator module.....	28

S	
Safety instructions	5
Seal label.....	5
Shutter	5
Signs.....	5
Status LEDs	
Deflection unit	12
Linear translator module.....	11
Stepper motor interface	29

T	
Technical data	13
Troubleshooting.....	51

W	
Warranty	10

X	
XY2-100 Standard	32

APPENDIX**Data Sheets:**

AXIALSCAN-20-C [100]

AXIALSCAN-20-C [250]

AXIALSCAN-20-DY [200]

AXIALSCAN-20-TY [200]

AXIALSCAN-20-Y [200]

AXIALSCAN-20-Y [600]

AXIALSCAN-30-C [100BO]

AXIALSCAN-30-C [200HP]

AXIALSCAN-30-C [250BO]

AXIALSCAN-30-C [300BO]

AXIALSCAN-30-C [600HP]

AXIALSCAN-30-Y

FOCUSSHIFTER