


---

# Hardware Manual

## SPI Interface Board (Extended)



This manual has been compiled by RAYLASE for its customers and employees.

RAYLASE reserves the right to change the product described in this manual and the information contained therein without prior notice.

The software included in the product and this manual itself are protected by copyright. All rights are reserved. Duplication of this manual in whole or in part, particularly by photocopying, scanning or imaging, and reproduction by any means are forbidden without the prior, written consent of RAYLASE.

**TABLE OF CONTENTS**

**1 BASIC INFORMATION..... 4**

1.1 Delivery Scope ..... 4

1.2 Warranty ..... 4

1.3 Signs..... 5

1.4 Conformity with directives ..... 5

1.5 Laser Safety ..... 6

1.6 Manufacturer ..... 6

1.7 Customer Support ..... 6

1.8 Disposal..... 6

**2 TECHNICAL DATA..... 7**

2.1 Dimension and Weight ..... 7

2.2 Environmental Conditions ..... 7

2.3 SET-UP Procedure..... 7

2.4 Connections..... 8

2.4.1 SPI Laser Interface..... 9

2.4.2 RS232..... 10

2.4.3 Laser Status ..... 10

2.4.4 External Start/Stop ..... 11

2.4.5 Cable Specifications..... 12

2.4.6 Status LEDs..... 12

**3 PROGRAMMING ..... 13**

3.1 Signals ..... 13

3.2 Commands ..... 13

3.3 Programming sequence ..... 14

# 1 BASIC INFORMATION

The RAYLASE SPI interface board is used to control a pulsed SPI laser in combination with RAYLASE control cards SP-ICE, RLC-PCI or RLC-USB.

## Features

- Interface to Ytterbium pulsed SPI Fiber Lasers according to interface types G3 or RM (basic interface)
- SCSI connector for 1:1 connection to SPI laser
- Detection, if the laser is attached or switched on
- Detection of laser error conditions
- Support of integrated visible pointer

## 1.1 Delivery Scope

- SPI interface board (Extended interface)
- Connecting cable between SPI interface board and control card (laser adapter)

## 1.2 Warranty

The rights of the customer in respect of any defects in quality or deficiencies in title are governed by the general conditions of business of RAYLASE AG. These conditions are available for review on our website.

Pack the product in the original packaging or in packaging that provides equivalent protection for shipping.


RAYLASE shall not be obliged to repair defects under the following circumstances:

- If persons not authorized by RAYLASE have attempted to repair the product.
- If persons not authorized by RAYLASE have modified the product.
- If the product has been used improperly.
- If the product has been connected to incompatible devices.

**Note:** No implicit guarantee or warranty of suitability for specific purposes has been made. RAYLASE is not responsible for damages arising from use of the product. Individual assemblies or other assemblies manufactured by RAYLASE may be subject to separate warranty conditions. Refer to the corresponding manuals for further information.

## 1.3 Signs


The following signs must be attached to the Interface Board. These signs may not be removed. Signs that have become illegible must be replaced.



The **rating plate** and the identification code printed on it allow the determination of the Interface Board type.



The **CE symbol** confirms the compliance of the Interface Board with European directives. It indicates that the Board is approved for free trade within the EU.



The **seal label** warns against unauthorized opening of the Interface Board. If the seal is broken, all warranty claims against RAYLASE are void.

## 1.4 Conformity with directives

The Interface Board conforms to the requirements of the following directives:

- EU Directive 2004/108/EC (EMC)
- WEEE Directive 2012/19/EC
- RoHS II 2011/65/EU

For details of conformity with other directives, contact RAYLASE.

## 1.5 Laser Safety

Customers assume all responsibility for maintaining a laser-safe working environment. OEM customers must assume all responsibility for CDRH (Center for Devices and Radiological Health) certification.

### **WARNING:**

Switch on the PC first, before switching on the laser system. In this way you can avoid an uncontrolled action of the laser when starting the control card.

## 1.6 Manufacturer

RAYLASE AG  
Argelsrieder Feld 2+4  
82234 Wessling  
Germany  
Tel.: +49 (0) 81 53 - 88 98 - 0  
Fax: +49 (0) 81 53 - 88 98 - 10  
<http://www.raylase.de>  
E-mail: [info@raylase.de](mailto:info@raylase.de)

## 1.7 Customer Support

The RAYLASE support services are available for your problems either in respect to the product or the accompanying manual. Before calling for support, please make sure you refer to any appropriate sections in the manuals on the supplied CD that may answer your questions.

If you need further assistance call RAYLASE customer service department, Monday through Friday between 8 A.M. and 6 P.M. (Middle European Time).

The customer service personnel will be able to give you direct assistance and answers to your questions.

Germany (Wessling)  
+49 (0) 81 53 - 88 98 - 0

... ask for the customer service department

## 1.8 Disposal

For the disposal of the Interface Board, note local policies, regulations and laws.

## 2 TECHNICAL DATA

### 2.1 Dimension and Weight

Dimensions: W 104mm, L 130mm, H 50mm

Weight: 440g

### 2.2 Environmental Conditions


Ambient temperature: +15°C to +35°C

Storage temperature: 0°C to +80°C

Humidity rel.: ≤80% non-condensing

### 2.3 SET-UP Procedure

Make sure that all requirements for laser safety, as described in the scan head manuals, are fulfilled. It is the user's responsibility to follow the regulations on laser safety.



**Fig. 1**  
Block diagram


#### Installation

- Connect power supply for laser.
- Connect RAYLASE control card via adapter to SPI interface board.
- Switch on laser power supply.

**Please note:** Interlock must be bridged for switching on the laser.

## 2.4 Connections

**Fig. 2**  
SPI interface  
board, overview



Designation	Description	Details
Input	RAYLASE control card (laser adapter)	---
Interlock	Safety switch	Must be bridged for switching in the laser
External Start/Stop	START MARK / STOP MARK input	Pin assignment ⇒ page 11
Laser Status	Status output	Pin assignment ⇒ page 10
RS232	Communication with PC	Pin assignment ⇒ page 10
Output	SPI laser interface	Pin assignment ⇒ page 9
Reset	Button for resetting the SPI interface board	---
Status LED's		⇒ page 12



**2.4.1 SPI Laser Interface**

J4	PIN	Signal	PIN	Signal
68 PIN SCSI	1	nc	35	nc
	2	Laser has pulsed I	36	GND
	3	Monitor. I	37	GND
	4	nc	38	nc
	5	Laser Emission Gate O	39	GND
	6	Pilot Laser Enable O	40	GND
	7	Global Enable O	41	GND
	8	Laser Temperature I	42	GND
	9	Alarm I	43	GND
	10	System_Fault I	44	GND
	11	Beam Delivery I	45	GND
	12	Laser Deactivated I	46	GND
	13	Pulse Trigger O	47	GND
	14	Laser is on I	48	GND
	15	Laser Disable O	49	GND
	16	Laser Emission Warning I	50	GND
	17	DI 0 O	51	DI 4 O
	18	DI 1 O	52	DI 5 O
	19	DI 2 O	53	DI 6 O
	20	DI 3 O	54	DI 7 O
	21	Laser Pulse/CW O	55	GND
	22	nc	56	GND
	23	nc	57	nc
	24	nc	58	GND
	25	TX O	59	DGND
	26	RX I	60	DGND
	27	nc	61	nc
	28	AGND	62	nc
	29	AGND	63	nc
	30	AGND	64	AI_2 O
	31	AGND	65	AI_1 O
	32	AGND	66	nc
	33	nc	67	nc
	34	nc	68	nc

I = Input, O = Output, nc = not connected

## Specifications

Output		
Output PNP open collector	5V	200mA

Input	
Input low	0.8V max.
Input high	2V min.

### 2.4.2 RS232

J6	Signal	PIN	Signal
1	nc	6	nc
2	RX I	7	nc
3	TX O	8	nc
4	nc	9	nc
5	GND	-	

I = Input, O = Output, nc = not connected

### 2.4.3 Laser Status

J7	Signal	PIN	Signal
1	nc	9	Laser has pulsed O
2	Monitor O	10	Laser Temperature O
3	Alarm O	11	System Fault O
4	Beam Delivery O	12	Laser Deactivated O
5	Laser is on O	13	Laser Emission Warning O
6	GND	14	AGND
7	nc	15	nc
8	nc		

I = Input, O = Output

**2.4.4 External Start/Stop**

PIN	Signal		PIN	Signal	
1	/LM	O	6	+5V	
2	/LMGATE	O	7	/MIP	O
3	/FPS	O	8	/Start-Mark	I
4	nc		9	/Stop-Mark	I
5	GND		-		

I = Input, O = Output, nc = not connected

**Specifications**




Output		
Output low	0.55V max.	64mA
Output high	2 - 5V	32mA

Input	
Input low	Refer to specifications of the RAYLASE control card
Input high	Refer to specifications of the RAYLASE control card

### 2.4.5 Cable Specifications

Connection	Length
SPI Interface Board to SPI Laser	max. 2m
External Start/Stop	max. 2m

### 2.4.6 Status LEDs

	Normal		Interlock open		Laser not connected
---	--------	---	----------------	---	---------------------

	Laser temperature		Beam delivery		System fault		Alarm
---	-------------------	---	---------------	---	--------------	---	-------

	Normal		Laser active
--	--------	--	--------------

### 3 PROGRAMMING

The following sections describe how to program an SPI laser for use with RAYLASE control card and RAYLASE SPI interface board.

#### 3.1 Signals

Use the following signals to program the SPI interface board:

Signals of control card	Description
/LM	Setting Pulse Repetition Rate of SPI Laser
/MIP	Switching On/Off the Global Enable Input of SPI Laser
/Analog Output	Setting Analog 0-10V Simmer Current of SPI Laser
/LMGATE	Switching On/Off the Laser Emission Input of SPI Laser
/PA 6	Monitoring of combined Error Outputs of SPI Laser
/PB0 ... /PB6	Laser Power
/PB0 ... /PB7	State Select
/PB7	Pulsed/CW-Mode
/Remote_Execute_1	Switch off Pilot Laser

#### 3.2 Commands

To program the SPI interface board use the following commands:

- Set\_Delays\_7\_8, Set\_Delays\_9\_10
- Write\_DA\_List, Write\_Port\_List
- Long\_Delay
- Read\_Port
- Write\_Port
- YAG1-Mode is required, Bit 4 = 0, Bit 5 = 1

See also the manual „Commands and Functions“ for details.

### 3.3 Programming sequence

#### Initialisation:

```
Init_Scan_Card (); // Initialise Scan Card
Load_Cor (lpstrFileName); // Load Correction File
Set_Mode (0x0420); // Set YAG1-mode (Bit 5 = 1, Bit
4 = 0)
```

#### Setting Master Oscillator input of SPI Laser with Control Commands:

```
Set_Start_List_1(); // Filling Job Data into List 1
Set_Delays_7_8 (t1, t2); // Set Laser Modulation Signal
Set_Delays_9_10 (t3, t4); // t4 = 0
Write_DA_List (value); // Set Laser Power
... // List Commands for Marking
Set_End_Of_List();
... // Start Marking
Write_Port (0x0C, 0x0010); // Switch-On Global Enable of SPI
Laser
... // Wait 10msec
Execute_List_1(); // Execute Job
...
Write_Port (0x0C, 0x0000); // Switch-Off Global Enable of
SPI Laser
```

#### Setting Master Oscillator input of SPI Laser with List Commands:

```
Set_Start_List_1(); // Filling Job Data into List 1
Write_Port_List (0x0C, 0x0010); // Switch-On Global Enable of SPI
Laser
Long_Delay 1000(); // Wait 10msec
Set_Delays_7_8 (t1, t2); // Set Laser Modulation Signal
Set_Delays_9_10 (t3, t4); // t4 = 0
Write_DA_List (value); // Set Laser Power
... // List Commands for Marking
Write_Port_List (0x0C, 0x0); // Switch-Off Global Enable of
SPI Laser
Set_End_Of_List();
...
Execute_List_1(); // Execute Job
```

#### Checking Laser Alarms and Resetting of SPI Laser:

```
Read_Port (0x08); // Read Bit 6 of Port A for
checking of Laser Alarm
// If Bit 6 set to FALSE then an
error occurred
...
Write_Port (0x0C, 0x0020); // Set Signal Remote_Execute_1 to
TRUE
... // Wait 1ms
Write_Port (0x0C, 0x0); // Set Signal Remote_Execute_1 to
FALSE
```

**INDEX**

<b>C</b>		<b>M</b>	
CE symbol.....	5	Manufacturer.....	6
Commands.....	13		
Conformity with directives .....	5	<b>R</b>	
Connections.....	8	Rating plate.....	5
Customer Support.....	6	RS232.....	10
<b>D</b>		<b>S</b>	
Delivery Scope.....	4	Seal label.....	5
Dimension.....	7	SET-UP Procedure.....	7
Disposal.....	6	Signals.....	13
		Signs.....	5
<b>E</b>		SPI Laser Interface.....	9
Environmental Conditions.....	7	<b>T</b>	
External Start/Stop.....	11	Technical Data.....	7
<b>F</b>		<b>W</b>	
Features.....	4	Warranty.....	4
		Weight.....	7
<b>I</b>			
Installation.....	7		
<b>L</b>			
Laser Safety.....	6, 7		
Laser Status.....	10		