

Hardware Manual IPG Interface Board



This manual has been compiled by RAYLASE for its customers and employees.

RAYLASE reserves the right to change the product described in this manual and the information contained therein without prior notice.

The software included in the product and this manual itself are protected by copyright. All rights are reserved. Duplication of this manual in whole or in part, particularly by photocopying, scanning or imaging, and reproduction by any means are forbidden without the prior, written consent of RAYLASE.

TABLE OF CONTENTS

1	BASIC INFORMATION	.4
1.1	Delivery Scope	. 4
1.2	Warranty	. 4
1.3	Signs	. 5
1.4	Conformity with directives	. 5
1.5	Laser Safety	. 6
1.6	Manufacturer	
1.7	Customer Support	. 6
1.8	Disposal	. 6
2	TECHNICAL DATA	.7
2.1	Dimension and Weight	.7
2.2	Environmental Conditions	. 7
2.3	SET-UP Procedure	.7
2.4	Connections	
2.4.1	IPG Laser Interface	
2.4.2	Laser Power Input and Laser Power Output	10
2.4.3	Cable Specifications	10

3	PROGRAMMING	11
3.1	Signals	
	Commands	
3.3	Programming sequence	

1 BASIC INFORMATION

The RAYLASE IPG interface board is used to control a pulsed IPG laser in combination with RAYLASE control cards SP-ICE, RLC-PCI or RLC-USB.

Features

- Interface to Ytterbium pulsed IPG Fiber Lasers according to interface types B, B1, B2, D
- D-SUB 25 connector for 1:1 connection to pulsed IPG laser
- Detection, if 24V power is attached. Soft start to switch on the laser.
- Optically isolated control signals
- Detection of laser error conditions
- Reset of laser after detection of laser error either by push-button or software
- Support of integrated visible pointer
- Emergency Stop input for immediate shut off of laser output

1.1 Delivery Scope

- IPG interface board
- Connecting cable between IPG interface board and control card
- Laser adaptor
- Hardware manual

1.2 Warranty

The rights of the customer in respect of any defects in quality or deficiencies in title are governed by the general conditions of business of RAYLASE AG. These conditions are available for review on our website.

Before returning the product, please request an authorization number from RAYLASE. Pack the product in the original packaging or in packaging that provides equivalent protection for shipping.

RAYLASE shall not be obliged to repair defects under the following circumstances:

- If persons not authorized by RAYLASE have attempted to repair the product.
- If persons not authorized by RAYLASE have modified the product.
- If the product has been used improperly.
- If the product has been connected to incompatible devices.
- If the product has been damaged because of inadmissible high laser power or focusing the laser on optical areas.
- If the product has been damaged because of unqualified cleaning of the optical areas.

Note: No implicit guarantee or warranty of suitability for specific purposes has been made. RAYLASE is not responsible for damages arising from use of the product. Individual assemblies or other assemblies manufactured by RAYLASE may be subject to separate warranty conditions. Refer to the corresponding manuals for further information.

1.3 Signs

The following signs must be attached to the Interface Board. These signs may not be removed. Signs that have become illegible must be replaced.



Rating plate

The rating plate and the identification code printed on it allow the determination of the Interface Board type.

The **CE symbol** confirms the compliance of the Interface Board with European directives. It indicates that the Interface Board is approved for free trade within the EU.

The **seal label** warns against unauthorized opening of the Interface Board. If the seal is broken, all warranty claims against RAYLASE are void.

1.4 Conformity with directives

The Interface Board conforms to the requirements of the following directives:

- EU Directive 2004/108/EC (EMC)
- WEEE Directive 2012/19/EC
- RoHS II 2011/65/EU

For details of conformity with other directives, contact RAYLASE.

1.5 Laser Safety

Customers assume all responsibility for maintaining a laser-safe working environment. OEM customers must assume all responsibility for CDRH (Center for Devices and Radiological Health) certification.

WARNING:

Switch on the PC first, before switching on the laser system. In this way you can avoid an uncontrolled action of the laser when starting the control card.

1.6 Manufacturer

RAYLASE AG Argelsrieder Feld 2+4 82234 Wessling Germany Tel.: +49 (0) 81 53 - 88 98 - 0 Fax: +49 (0) 81 53 - 88 98 - 10 http://www.raylase.de E-mail: info@raylase.de

1.7 Customer Support

The RAYLASE support services are available for your problems either in respect to the product or the accompanying manual. Before calling for support, please make sure you refer to any appropriate sections in this manual that may answer your questions.

If you need further assistance call RAYLASE customer service department, Monday through Friday between 8 A.M. and 4 P.M. (Middle European Time).

The customer service personnel will be able to give you direct assistance and answers to your questions.

Germany (Wessling) +49 (0) 81 53 - 88 98 - 0

... ask for the customer service department

1.8 Disposal

For the disposal of the Interface Board, note local policies, regulations and laws.

2 TECHNICAL DATA

2.1 Dimension and Weight


Dimensions: W 85mm, L 103mm, H 30mm Weight: 400g

2.2 Environmental Conditions

Ambient temperature:+15°C to +35°CStorage temperature:0°C to +80°CHumidity rel.:≤80% non-condensing

2.3 SET-UP Procedure


Make sure that all requirements for laser safety, as described in the scan head manuals, are fulfilled. It is the user's responsibility to follow the regulations on laser safety.



Installation

- Connect power supply for laser to J1.
- Connect laser power supply output J2 to IPG laser.
- Connect IPG interface board output J4 to laser interface.
- Connect RAYLASE control card via adapter to IPG interface board input J3.
- Switch on laser power supply. After a short delay, the laser will be switched on.

Please note: J5 must be connected to switch on the laser.



2.4 Connections

ID	Assignment	Details
J1	Laser Power Input (24V)	
J2	Laser Power Output	
J3	IPG Interface Input	
J4	IPG Interface Output	page 9
J5	Shutter / Emergency Stop	must be connected to switch-on the laser
T1	Laser Reset	resets the laser or the IPG interface in case of a fault

J4	PIN	Signal	PIN	Signal
	1	D0	14	GND
1	2	D1	15	nc
	3	D2	16	Alarm1
	4	D3	17	nc
13 99	5	D4	18	MO / EE
K.	6	D5	19	Laser Modulation
6 ²⁵	7	D6	20	PRR / Sync [interface type D]
25 PIN D-SUB	8	D7	21	Alarm2
	9	Latch	22	Pointer
	10	GND	23	Emergency stop
	11	Alarm3	24	nc
	12	Alarm4	25	nc
	13	nc		

IPG Laser Interface 2.4.1

EE = Emission Enable LM = Laser modulation

MO = Master oscillator [interface type B] nc = Not connected

PRR = Pulse Repetion Rate [interface type B]

Specifications

Output		
Output low	max. 0.55V	64mA
Output high	2.0 – 5.0V	32mA

J1, J2	PIN	Signal
0.0.0.0	1	24V
1 2 3	2	Return
Laser power interconnection	3	Safety Ground

2.4.2 Laser Power Input and Laser Power Output

2.4.3 Cable Specifications

Connection	Cross-section	Length	Signals
24V power supply – J1	min. 3x2,5mm ²		
J2 – IPG laser	min. 3x2,5mm ²	max. 2m	
J4 – IPG laser		max. 2m	1:1

2.4.4 Status LEDs

LED				Meaning	
1	2	3	4		
green	-	-	-	5V Input	Voltage from control card is ready
-	green	-	-	24V Input	Voltage for laser is ready
-	-	red	-	24V Output	Soft start process of IPG laser is active.
-	-	green	-	24V Output	IPG laser is powered up
-	-	-	red	Laser emission ON	Laser is active

LED			Meaning
5	6	7	
green	green	green	Normal state
yellow	green	green	Laser not ready (only interface type D)
yellow *	-	-	Shutter open (combinations with other fault possible)
-	-	red	Laser temperature out of range
-	red	-	Powersupply out of range (only interface type D)
red	-	-	Back Reflection error
red*	red*	red*	Internal system error

* flashing

3 PROGRAMMING

The following sections describe how to program an IPG laser for use with RAYLASE control card and RAYLASE IPG interface board.

3.1 Signals

Use the following signals to program the IPG interface board:

Signals of control card	Description
/LM	Setting Input Pulse Repetition Rate of IPG Laser
/MIP	Switching On/Off the Master Oscillator Input of IPG Laser
/FPS	Setting Power Setting Latch Input of IPG Laser
/PB 0-7	Setting 8 Bit Power Inputs of IPG Laser
/LM_Gate	Switching On/Off the Laser Modulation Input of IPG Laser
/Remote_Execute 1	Reset IPG Laser after Detection of Alarm Condition
/PA 6	Reading of combined Alarm1 to Alarm3 outputs of IPG Laser

3.2 Commands

To program the IPG interface board use the following commands:

- Set_Delays_7_8, Set_Delays_9_10
- Write_Port_List
- Long_Delay
- Read_Port
- Write_Port
- YAG1-Mode is required, Bit 4 = 0, Bit 5 = 1

See also the manual "Commands and Functions" for details.

3.3 Programming sequence

```
Initialisation:
```

```
Init_Scan_Card (); // Initialise Scan Card
Load_Cor (lpstrFileName); // Load Correction File
Set_Mode (0x0420); // Set YAG1-mode (Bit 5 = 1, Bit
4 = 0)
```

```
Setting Master Oscillator input of IPG Laser with Control Commands:
                               // Filling Job Data into List 1
Set Start List 1();
Set Delays 7 8 (t1, t2);
                                   // Set Laser Modulation Signal
                                   // t4 = 0
Set Delays 9 10 (t3, t4);
Write_Port_List (0x0A, value); // Set Laser Power
                                   // List Commands for Marking
. . .
Set End Of List();
                                   // Start Marking
. . .
                                   // Switch-On Master Oscillator of
Write Port (0x0C, 0x0010);
                                   IPG Laser
                                   // Wait 10msec
. . .
Execute List 1();
                                   // Execute Job
. . .
Write Port (0x0C, 0x0000);
                                   // Switch-Off Master Oscillator
```

of IPG Laser

Setting Master Oscillator input of IPG Laser with List Commands:

```
// Filling Job Data into List 1
Set Start List 1();
Write Port List (0x0C, 0x0010);
                                   // Switch-On Master Oscillator of
                                   IPG Laser
                                   // Wait 10msec
Long Delay 1000();
Set_Delays_7_8 (t1, t2);
                                   // Set Laser Modulation Signal
                                   // t4 = 0
Set Delays 9 10 (t3, t4);
Write_Port_List (0x0A, value);
                                   // Set Laser Power
                                   // List Commands for Marking
Write Port List (0x0C, 0x0);
                                   // Switch-Off Master Oscillator
                                   of IPG Laser
Set End Of List();
. . .
                                   // Execute Job
Execute List 1();
```

Checking Laser Alarms and Resetting of IPG Laser:

```
Read_Port (0x08); // Read Bit 6 of Port A for
checking of Laser Alarm
// If Bit 6 set to FALSE then an
error occured
...
Write_Port (0x0C, 0x0020); // Set Signal Remote_Execute_1 to
TRUE
... // Wait 1ms
Write_Port (0x0C, 0x0); // Set Signal Remote_Execute_1 to
FALSE
```

INDEX

С

C	
CE symbol	5
Conformity with directives Connections	5 8
Customer Support	
5	
D	
Delivery Scope Dimension	4
Disposal	
·	
E	
Environmental Conditions	7
F	
F	
Features	4
I	
Installation	7

L
Laser Safety 6, 7
Μ
Manufacturer 6
R
Rating plate 5
S
Seal label
т
Technical Data7
W
Warranty4 Weight7